



Make sure the weatherstrip is seated properly in the run channel. Refer to Figure 17.

Condition

There is windnoise from the T-top.

Cause

Figure 18



The T-top may not be seated against the roof seal. A business card should not be able to easily slip between the T-top and the seal.

Correction

Remove the shim under the striker.


Condition

There is windnoise around the mirror patch (convertible, hard top, T-top models).

Cause


The door glass or the mirror patch may need adjustment. Refer to Figures 19, 20 and 21.

Figure 19




Align the mirror patch applique with the door open and the window up. The applique should be perfectly in line with the window or it should have a slight "bump" in the seal at the top of the mirror patch applique. Refer to Figure 19 for location.

Figure 20



With the door open and the window up, apply pressure on the weatherstrip with a finger at the location shown by the arrow in Figure 20. The weatherstrip should not move.

Figure 21



If the glass is not adjusted properly for height at the arrow, it will cause a bulge in the seal and create a windnoise. Refer to Figure 21.

Condition


There is road noise or windnoise around the mirror patch (convertible, hard top, T-top models).

Cause

The foam blocker may not be in place.

Correction

Figure 22



Remove the foam blocker and split the difference between the upper and the lower part of the trim pad. Refer to Figure 22.

Correction

Adjust the mirror patch or the door glass. Refer to General Information on Door Glass Adjustments later in this bulletin.

Condition


There is a water leak in the rear compartment.

Cause

The taillamp harness grommet may not be seated properly.

Correction

Figure 23



Make sure that the grommet lip is seated properly. Refer to Figure 23.

Condition


There is a water leak in the rear compartment (hard top, T-top models).

Cause

The rear compartment primary seal may not be seated properly.

Correction

Figure 24



Center the weatherstrip in the opening and install the weatherstrip. Make sure the seal is fully seated to the hem flange. Refer to Figure 24.

Condition


There is a water leak in the rear compartment (convertible models).

Cause

The rear compartment primary seal may not be seated properly.

Correction


Figure 25



Center the weatherstrip in the opening and install the weatherstrip. Make sure the seal is fully seated to the hem flange. Refer to Figure 25.

Condition

Figure 26



There is a water leak in the rear hatch (hard top, T-top models). Some customers may comment that when the rear hatch is opened, water runs out of one or both front lower corners. Refer to Figure 26.


Cause

Sealing operations may have been missed at the two locations during assembly.

- The sealer may be missing at both of the lower front corners.
- The sealer may be missing downward from the hinges.

Correction

Figure 27



- Open the rear hatch to make sure there is no trapped water.


Important: Wear safety glasses and use compressed air to dry the area.

- Determine which area needs to be sealed. Refer to Figures 26 and 27.
- Clean the surface to be sealed using one of the following, or an equivalent:
 - 3M® General Purpose Adhesive Cleaner, P/N 08984
 - Dominion Sure Seal, Sure Solve Stock BSS
 - Kent Acrosol™
- Seal the flange(s) using one of the following, or an equivalent:
 - 3M® Ultropro™ Autobody Sealant
 - Kent High Tech Seam Sealer Clear 10200
 - Dominion Sure Seal Heavy Duty Drip Check LSC Item #9019

Condition

Water drips from the left hand side strut attachment on the deck lid (hard top, T-top models).

Cause

Figure 28

A plug may be missing from under the left side spoiler. Refer to Figure 28.

Correction

Remove the spoiler and install plug, P/N 10231979.


General Information on Door Glass Adjustments

Important: On frameless door glass, always check and verify door alignment to the body prior to adjusting the door glass. Some items may require that the door glass be adjusted. It is important that the door glass be able to contact and seal to the weatherstrip when operating the glass with the door closed ("reroll"). Always check the ability to "reroll the door glass" with the door in the closed position when door glass adjustments are made.

The glass is not parallel to the weatherstrip or is not contacting the up stops at the same time.

1. Lower the glass part way and raise to within 25 mm (1 in) from the weatherstrip.

Figure 29



2. Loosen the inner panel cam attachments. Refer to item 1 in Figure 29. The front attachment is slotted for adjustment
3. Position the glass parallel to the weatherstrip and tighten the attachments.

Tighten

Tighten the attachments to 10 N·m (89 lb in).

The glass is forward or rearward.


1. Loosen the rear guide channel attachments. Refer to item 2 in Figure 29.
2. Position the glass to the desired location and tighten the attachments.

Tighten

Tighten the attachments to 27 N·m (20 lb ft).

This glass is up or down at the front.

Figure 30



- Loosen the front up stop attachment. Refer to item 1 in Figure 30.
- Position the glass to the desired location and tighten the attachments.

Tighten

Tighten the attachments to 10 N·m (89 lb in).

The glass is up or down at the rear.

1. Loosen the rear up stop attachment in the rear guide channel.
2. Position the glass to the desired location and tighten the attachments.

Tighten

Tighten the attachments to 10 N·m (89 lb in).

The upper edge of the glass is inboard or outboard.

1. Loosen the rear guide channel attachments
2. Loosen the front up stop in/out attachment (access through the hole in inner panel rearward of the front up stop). Refer to item 2 in Figure 30.

Important: The front up stop will "float" in or out as the jack screws are adjusted in or out.

- Adjust the rear guide channel jack screws in or out as desired.

Tighten


- Tighten the rear guide channel attachments to 27 N·m (20 lb in).
- Tighten the front up stop in/out attachment to 10 N·m (89 lb in).

Belt stabilizers will reduce noise during glass travel or improve glass stability. Refer to item 3 in Figure 30.

- With the glass in the full up position, loosen the stabilizer attaching screw.
- Apply slight outboard pressure on the glass.
- Tighten the stabilizer attaching screw.

Important: If the glass binds or moans/squeaks during travel, loosen stabilizer and reposition it slightly inboard to reduce pressure on the door glass.

Figure 31



Adjust the window to the proper height to the roof weatherstrip. Then adjust the mirror patch to fit the door glass and the "A" pillar. Refer to item 1 in Figure 31 for up down and for and aft adjust. Refer to item 2 in Figure 31 for in and out adjustment.

Parts Information

| Part Number | Description |
|-----------------|-----------------------------------|
| 12345097 (U.S.) | Weatherstrip Adhesive Gel (Black) |

| | |
|-------------------|-------------------------------------|
| 10953479 (Canada) | |
| 12345739 (U.S.) | RTV Silicone Rubber Sealant (Black) |
| 10953541 (Canada) | |

Parts are currently available from GMSPO.

Warranty Information

Dealers should use the closest labor operation code for each separate repair operation.

For individual repair operations that require labor time in excess of 0.5 hr, prior District Service Manager approval is required.

GM bulletins are intended for use by professional technicians, NOT a "do-it-yourselfer". They are written to inform these technicians of conditions that may occur on some vehicles, or to provide information that could assist in the proper service of a vehicle. Properly trained technicians have the equipment, tools, safety instructions, and know-how to do a job properly and safely. If a condition is described, DO NOT assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your GM dealer for information on whether your vehicle may benefit from the information.



WE SUPPORT
VOLUNTARY
TECHNICIAN
CERTIFICATION