


A

97- 04 Factory Vette Accessories



B

IROC/TA with Factory Accessories & S&P Wide Style Air Bracket. Also a complete line of dress up Aluminum pulleys and covers for your GTO / IROC / TA.



C

98 - 02 LS1 ENGINE (CAMARO / TA)  
Factory set-up



D

IROC/TA with Factory Accessories & S&P Low Pass. Side Air

Replacement Pulleys Now Available in Aluminum for your Factory Accessories



E

99 - Up 4.8, 5.3, 6.0 ENGINE  
Factory set-up



F

Factory Type Alum. P.S Pulley  
See Page 76



IROC/TA with Factory P.S & S&P Low Pass. Side Air & Upper Pass. Alt