

ATI ProCharger
LS1 F-BODY 6 RIB BELT / PULLEY MATRIX
Matrix for 5.82" (6") crank pulley

CRANK PULLEY	BLOWER PULLEY	BELT
DC017A-006	DP300I-06D	DB355I-006
DC017A-006	DP310I-06D	DB355I-006
DC017A-006	DP320I-06D	DB355I-006
DC017A-006	DP340I-06D	DB355I-006
DC017A-006	DP350I-06D	DB365I-006
DC017A-006	DP360I-06D	DB365I-006
DC017A-006	DP370I-06D	DB365I-006
DC017A-006	DP385I-06D	DB370I-006
DC017A-006	DP400I-06D	DB370I-006
DC017A-006	DP410I-06D	DB370I-006
DC017A-006	DP425I-06D	DB374I-006
DC017A-006	DP438I-06D	DB374I-006
DC017A-006	DP450I-06D	DB374I-006
DC017A-006	DP463I-06D	DB380I-006
DC017A-006	DP475I-06D	DB380I-006

Replacement Idler: DC003A-061 2.3" idler with bearings
Idler shaft: DM008A-002
Blower pulley spacer PDW01C-075 .075" D series impeller shim

Install notes

Remove the driver's upper and the lower stand to bracket mounting bolts and loosen the passenger upper bolt to allow bracket to be pivoted enough for the belt to be installed over the lower standoff. Hang the belt on the standoff and install and tighten all stand to bracket bolts.

Some belts will be easier to install if you pivot the supercharger in the bracket using the lower mounting bolt only. Install the belt over the crank pulley and then finish installing the blower mounting bolts. The anti-sway bar may need to be lowered to facilitate installation of some of the mounting bolts.

Tech assistance is available from ProCharger M-F 9-5 central
913-338-2886



