

**Table A**

Common vehicle ECM/PCM tachometer signal wiring information						
Vehicle	Year(s)	ECM/PCM	ECM/PCM location**	Pin	Wire color	Circuit #
Camaro & Firebird	1996-1997	32U	Connector C1 (Red)	13	White	121
Camaro & Firebird	1998	Warren	Connector C2 (Blue)	35	White	121
Camaro & Firebird	1999-2002	Warren	Connector C2 (Red)	10	White	121
Camaro	2010-2013	E38	Connector C1 (Black)	48	N/A	N/A
C/K Truck*	2000-2006	Warren	Connector C2 (Red or Green)	10	White	121
C/K Truck*	2007-2012	E38	Connector C1 (Black)	48	N/A	N/A
Corvette	1995-1996	32U	Connector C1 (Red)	13	White	121
Corvette	1997-1998	Warren	Connector C2 (Blue)	35	White	121
Corvette	1999-2003	Warren	Connector C2 (Red)	10	White	121
Corvette	2004	Warren	Connector C2 (Green)	10	White	121
Corvette	2005	E40	Connector C1 (Blue)	48	White	121
Corvette	2006-2007	E38	Connector C1 (Black)	48	White	121
Corvette	2008-2013	E38	Connector C1 (Black)	48	White	121
Corvette ZR1	2009-2013	E67	Connector C1 (Blue)	25	White	121
CTS-V	2004-2005	Warren	Connector C2 (Green)	10	White	121
CTS-V	2006-2007	E67	Connector C1 (Blue)	25	White	121
CTS-V	2009-2013	E67	Connector C1 (Blue)	25	N/A	N/A
GTO	2004	Warren	Connector C2 (Green)	10	Brown	121
GTO	2005-2006	E40	Connector C1 (Blue)	48	Brown	121
SSR	2003-2004	Warren	Connector C2 (Blue)	10	White	121
SSR	2005-2006	E40	Connector C1 (Blue)	48	White	121
Trailblazer SS	2006	E40	Connector C1 (Blue)	48	White	121
Trailblazer SS	2007	E67	Connector C1 (Blue)	25	White	121
Trailblazer SS	2008-2009	E67	Connector C1 (Blue)	25	White	121

\* VIN C/K Trucks include:

- For 2000-2013:
  - Chevrolet Avalanche, Suburban, Tahoe, and Silverado
  - GMC Yukon and Sierra
  - Cadillac Escalade

\*\* Connectors C1, C2, and C3 (or X1 and X2) may be labeled as J1, J2, and J3 on the ECM itself.