


## Cylinder Head/Upper Engine



- (100) Engine Block
- (209) Valve Lifter
- (210) Valve Lifter Guide
- (211) Bolt
- (212) Pushrod
- (213) Valve Rocker Arm
- (214) Bolt
- (215) Valve Rocker Arm Pivot Support
- (216) Core Hole Plug
- (217) Cylinder Head Gasket

(218) Cylinder Head  
(220) Cylinder Head Bolt - M11  
(221) Cylinder Head Bolt - M8  
(222) Valve Stem Oil Seal  
(223) Valve Spring  
(224) Valve Spring Cap  
(225) Valve Stem Key  
(226) Core Hole Plug  
(227) Intake Valve  
(228) Exhaust Valve  
(229) Cylinder Head Plug  
(230) Cylinder Head Locating Pin  
(422) O-ring  
(423) Oil Fill Tube  
(424) Oil Fill Cap  
(450) O-ring  
(504) Valve Rocker Arm Cover Gasket  
(504) Valve Rocker Arm Cover Gasket  
(505) Valve Rocker Arm Cover  
(505) Valve Rocker Arm Cover  
(515) Bolt Grommet  
(516) Bolt  
(558) Plug  
(600) Exhaust Manifold  
(601) Exhaust Manifold Gasket  
(602) Bolt  
(603) Exhaust Manifold Heat Shield  
(604) Bolt  
(605) Stud  
(700) Positive Crankcase Ventilation (PCV) Hose - Fresh Air  
(719) Ignition Coil Bracket  
(720) Stud  
(721) Ignition Coil Wire Harness Assembly  
(722) Ignition Coil  
(723) Bolt  
(724) Spark Plug Wire  
(725) Coolant Temperature Sensor (CTS)  
(726) Spark Plug