

### PCM Connector C1 Blue

Pin #	Wire Color	Circuit #	Function	A4	M6
17	DK BLU	1225	Transmission fluid pressure switch signal B	X	
18	RED	1226	Transmission fluid pressure switch signal C	X	
32	GRY	48	Clutch pedal position switch (manual cars only)		X
33	PPL	420	TCC brake switch signal	X	
34	ORN/BLK	434	PNP switch (grounded in park and neutral)	X	
41	BLK	407	Transmission temp sensor low reference	X	
53	BLK	407	Sensor ground (trans fluid temperature sensor)	X	
79	WHT or GRY	687	3-2 Shift solenoid control		X

### PCM connector C2 Red

Pin #	Wire color	Circuit #	Function	A4	M6
2	BRN	418	TCC PWR Solenoid valve control	X	
6	RED/BLK	1228	PC solenoid valve high control (to trans sol A)	X	
8	LT BLU/WHT	1229	PC solenoid valve low control (to trans sol A)	X	
42	TAN/BLK	422	TCC Solenoid valve control	X	
44	LT GRN	1652	Reverse lockout solenoid ( manual cars only)		X
47	YEL/BLK	1223	2-3 shift solenoid (solenoid B) control	X	
48	LT GRN	1222	1-2 shift solenoid (solenoid A) control	X	
51	YEL/BLK	1227	Transmission fluid temperature sensor	X	
63	PNK	1224	Transmission fluid pressure switch signal A	X	