Document ID# 1837415 2004 Cadillac CTS



Subject: Info - Release of DEXRON VI Automatic Transmission Fluid (ATF)

#04-07-30-037B - (06/12/2006)

Models: 2007 and Prior Passenger Cars and Light Duty Trucks

2003-2007 HUMMER H2

2006-2007 HUMMER H3

2005-2007 Saturn Relay

2005 and Prior Saturn L-Series

2005-2007 Saturn ION

2005-2007 Saturn VUE with 4T45-E

2005-2007 Saab 9-7X

Except 2007 and Prior Chevrolet Aveo, Epica, Equinox, Optra

Except 2007 and Prior Pontiac Torrent, Vibe, Wave

Except 2003-2005 Saturn ION with CVT or AF23 Only

Except 1991-2002 Saturn S-Series

Except 2007 and Prior Saturn VUE with CVT, AF33 or 5AT (MJ7/

MJ8) Transmission Only

This bulletin is being updated with the 2007 model year. Please discard Corporate Bulletin

Number 04-07-30-037A (Section 07 -- Transmission/Transaxle).

DEXRON®-VI ATF

General Motors Powertrain has recently upgraded to DEXRON®-VI ATF with the start of 2006 vehicle production.

Only 2005 and prior models that currently use DEXRON®-III may use DEXRON®-VI as a replacement.

All 2006 and future models that use DEXRON®-VI are to be serviced with DEXRON®-VI fluid only.

DEXRON®-VI is an improvement over DEXRON®-III in the following area:

DEXRON®-VI	
Extended Eastery Fill For Life	160,000 km (100,000 mi) For Cars and Light Duty Trucks*
Extended Factory Fill For Life	80,000 km (50,000 mi) (Severe Use) For Cars and Light Duty Trucks*
Clutch Friction Stability	Improved 100%
Clutch Durability Due To Fluid	Improved 120%
Oil Film Thickness	Increased 20%
Fluid Oxidation	Improved 100%
Foam/Aeration	Improved 150%
Shear Stability	Improved 200%

^{*} These ATF change intervals remain the same as DEXRON®-III for the time being.

2006-2007 Transmission Fill and Cooler Flushing

Some new applications of the 6L80 six speed transmission will require the use of the J 45096 - Flushing and Flow Tester to accomplish transmission fluid fill. It is highly recommended that the clean oil reservoir of the machine be purged of DEXRON®-III and filled with DEXRON®-VI.

Parts Information

Part Number	Description
88861003 (US)	DEXRON®-VI Auto Trans Fluid (1 qt bottle)
88861045 (US)	DEXRON®-VI Auto Trans Fluid (1 gal bottle)
88861046 (US)	DEXRON®-VI Auto Trans Fluid (55 gal drum)
88861004 (Canada)	DEXRON®-VI Auto Trans Fluid (1L bottle)
88861043 (Canada)	DEXRON®-VI Auto Trans Fluid (4L bottle)
88861044 (Canada)	DEXRON®-VI Auto Trans Fluid (205L drum)

GM bulletins are intended for use by professional technicians, NOT a "do-it-yourselfer". They are written to inform these technicians of conditions that may occur on some vehicles, or to provide information that could assist in the proper service of a vehicle. Properly trained technicians have the equipment, tools, safety instructions, and know-how to do a job properly and safely. If a condition is described, DO NOT assume that the bulletin applies to your vehicle, or that your vehicle will have that condition. See your GM dealer for information on whether your vehicle may benefit from the information.



© Copyright General Motors Corporation. All Rights Reserved.

Document ID# 1837415 2004 Cadillac CTS